
## **POINTER PLATE**

## R∰₩S



**OTLK-A** 



0.3	IMAO
	Body
	SUS304 stainless steel

Part Number	Weight (g)
OTLK40-A	21

## How To Use

•Use with scale plate for reading graduations in radial feeding applications such as rack and pinion.

• Insert Pointer Plate to the slot on the base component of One-Touch Locking Knobs.

